GONSU

STEP-LIGHT SELECTION & INSTALLATION NOTES

Step-light selection & installation notes



01 / Position & sightlines

Coordinate the fitting with treads, side walls, skirting and walking direction. Check source visibility from different viewpoints. Set spacing and height using the selected light distribution and site conditions, not unverified universal values.

02 / Recesses & maintenance

Before construction, confirm finished surfaces, cut-outs, recess depth, back boxes and driver locations, with access for maintenance. Do not determine cut-outs or wiring from promotional images without the model instructions.

> General selection guidance. Supplied promotional illustrations are not completed-project photography or test evidence. Confirm dimensions, wattage, electrical data, protection ratings and certification scope for the selected model.

CONTROLS / ENVIRONMENT / SAFETY

Check again before installation

03 / Power & electrical safety

Use appropriately qualified personnel and follow the product instructions and applicable regulations. Confirm voltage, driver, earthing or insulation requirements by model; there is no universal wiring instruction for all fittings.

04 / Sensors & use

For sensor versions, test arrival directions, obstructions, ambient light and neighbouring fittings on site. Detection range, delay, daylight response and dimming depend on the selected model.

05 / Environmental suitability

For outdoor, damp or wash-down exposure, check protection ratings and intended use. An indoor illustration is not proof of outdoor suitability or a substitute for testing and certification documents.

06 / Lighting role & validation

Step lights provide supplementary low-level light and guidance, not a replacement for general lighting or legally required emergency lighting. Validate the result with actual finishes, other light sources and sample testing.

> General information only, not a model-specific installation manual or project design document.